

7300 Net Bag and Ring Assembly Instructions

The net is assembled by inserting one end of the ring into the hem of the bag. The ring is the flat wire. The hem is the sail cloth band at the top of the net bag. Push the ring into the hem opening until it reaches half way through. At this point, put both hands on the hem and thread the ring the rest of the way through the hem. At this point the ring will start to bend into the round shape that the net will assume. There is a return in the fabric at the end of the hem before the ring exits. Make sure the ring makes it all the way out of the hem. You should now have both ends sticking out of the net bag. Install the lock screw into the end of the handle, leaving the hole open enough to insert the ends of the ring. Insert one ring end through the hole, followed by the other one. Adjust the overlap of the ring ends so that they are even and the bag sits evenly on the ring. If the bag appears to be bunched up on the ring, expand the ring in the hole so that the bag sits evenly on the ring. Tighten the lock screw and you're done.